

DRYER MASHER



INSTRUCTION MANUAL

Product structure



Product features:



Improve Drying Efficiency



Soften Fabrics



Detergent-Free



Refillable For Softener Beads



Clean Scent



Reusable



Eco-Friendly

How to use

1. Always follow fabric care instructions when using tumble dryer.
2. Make sure you have sufficient amount of softener beads inside the dryer masher.
3. Place the dryer masher in the load together with laundry in tumble dryer.
4. Set desired dryer setting on machine. The dryer masher can be used in all temp settings.
5. Start tumble dryer!
*The set amount of softener beads can be use up to 30 drying cycles. When running low, be sure to refill with Dryer Masher Softener Beads.

Warning

1. Do not put into washing machine.
2. Dryer Masher is not a toy and should be kept away from children and pets.

Product specification:

Product Size	86 x 86 x 75mm
Weight	113g




The device complies with the European Directives 2014/30/EU.

DRYER MASHER



INSTRUCTION MANUAL

Product structure



Product features:



Improve Drying Efficiency



Soften Fabrics



Detergent-Free



Refillable For Softener Beads



Clean Scent



Reusable



Eco-Friendly

How to use

1. Always follow fabric care instructions when using tumble dryer.
2. Make sure you have sufficient amount of softener beads inside the dryer masher.
3. Place the dryer masher in the load together with laundry in tumble dryer.
4. Set desired dryer setting on machine. The dryer masher can be used in all temp settings.
5. Start tumble dryer!
*The set amount of softener beads can be use up to 30 drying cycles. When running low, be sure to refill with Dryer Masher Softener Beads.

Warning

1. Do not put into washing machine.
2. Dryer Masher is not a toy and should be kept away from children and pets.

Product specification:

Product Size 77 x 77 x 92mm

Weight 118g



The device complies with the European Directives 2014/30/EU.